



STANDARD OPERATING PROCEDURE FOR GREEN POWER CHARGER (GP-AXA 2)



SAFETY NOTES

- ❖ It is advisable that an appropriate area be selected and designated for charging.
- ❖ A wash station should be supplied at all charging stations as there is always a risk of acid splashes.
- ❖ Select a well ventilated area for charging. Ensure that the charging area is clean and tidy.
- ❖ There is a possibility of the terminals being short circuited.
- ❖ Remove filler caps and top up with distilled water if required.
- ❖ Replace filler caps loosely.
- ❖ Clean battery terminals.
- ❖ Ensure correct voltage is selected.
- ❖ Switch off the charger before disconnecting/connecting battery.
- ❖ Do not connect reverse polarity to the battery.

OPERATING PROCEDURE

Step 1: - Connect input AC power of the charger to input supply at the workshop.

Step 2: - Connect the Red cable to positive and Black cable to negative terminals of the charger.

Step 3: - Connect the Red clamp to the positive terminal and Black clamp to the negative terminals of the battery.

Step 4: - Switch **ON** the power button from back side of the charger, the display will start. The charger will indicate “**AC OK WAIT**”.

Step 5: - Together press **Enter** & **Amp** button for 4- 5sec, charger will switch to setting mode & will flash the Amp and voltage in LCD.

Step 6: - Press ‘**V**’ button to change the system voltage i.e. for one battery 12 V and for two batteries 24V.

Step 7: - Press **Amp** button to change the Ampere setting depending on the capacity of the battery.

Step 8: - Press **Enter** to complete the setting and the charging process will start.

Indications in the LCD appearing are: -

SYS 12	12.0V
STG 1	8.00A



Step 9: - Switch off the charger when **Charge Finish** is displayed on the screen.

Note 1: -Battery will go to float/sleep mode after the charge finish is indicated.

2:- For connecting 2 nos. of batteries (24V system), please connect the batteries in series.

Symptoms & Precautions

Charger not starting: -

- Check the fuse at the back side of the charger. Use same rating (10A, 250V)
- Check input supply.(>120V)
- Check if the proper Earthing is available.

“Check Connection Polarity”

- Check if the correct polarity is connected (Red cable to +ve & Black cable to –ve)
- Check if the battery is below 5 V.
- Check if the battery is damaged/shorted.
- Check if the parameters are set correctly as per the connection.

Note: - Please select the AMP (Current) setting for the particular battery depending on the capacity of batteries recommended by manufacturers.

The charger has the following current setting available for the batteries.

- 2 Amps: - 35 Ah and less
- 4 Amps: - 45Ah to 55 Ah
- 6 Amps: - 60 Ah to 75 Ah
- 8 Amps: - 80 Ah and more.

For Service Complaints: -

Apple Energy Pvt. Ltd.

G-15/406, Hilton Centre, Sector-11,
CBD Belapur, Navi Mumbai-400614, India.
Tel.:91-22-27564033/32/103.

E-mail: greenpower@appleenergy.in